

Instrument Description

1. Display
2. BNC socket
3. RS232 output terminal
4. RMS/PEAK switch
5. Acceleration/Velocity switch
6. Data hold button
7. Power button
8. RECORD button
9. RECALL button
10. Battery compartment/cover
11. BNC plug
12. Mini plug
13. Vibration sensor input socket
14. Vibration sensor
15. Magnetic base

